

# Installation and Assembly - Projector Adapter Plate for InFocus™ IN24 and IN26 Projectors

Models: PAP 277, PAP 277-S,  
PAP 277-W

Before you start check the parts list below to make sure all of the parts shown are included.

**IMPORTANT!** Read entire instruction sheet before you start installation and assembly.


## ⚠ WARNING

- Installer must verify that the supporting surface will safely support the combined weight of all attached equipment and hardware.

### Parts List

| Description                                    | Qty. | PAP 277  | PAP 277-S | PAP 277-W |
|--|------|----------|-----------|-----------|
| <b>AA</b> adapter plate                        | 1    | 055-1680 | 055-4680  | 055-2680  |
| <b>BB</b> M4 x 16mm socket pin screw           | 3    | 520-1087 | 520-2087  | 520-2087  |
| <b>CC</b> retaining spacer .198 x .313 x .375h | 3    | 590-2020 | 590-2009  | 590-2009  |
| <b>DD</b> 4mm security allen wrench            | 1    | 560-9646 | 560-9646  | 560-9646  |

Note: Actual parts may appear slightly different than illustrated.



- 1 \*Notch indicates front of projector.  
Flip projector upside down. Fasten adapter plate (AA) using three retaining spacers (CC) and three M4 x 16mm socket pin screws (BB). Tighten M4 x 16mm socket pin screws (BB) through clearance holes in adapter plate (AA) using 4 mm security allen wrench (DD).

